

To lock the Sharpak XL container prior to disposal, follow the instructions below



When ready for disposal the slide lid should be fully closed



To lock, fully depress the button with thumb



Ensure that the button is fully depressed and that the lid is securely locked



The container is then ready for disposal

